





## FUEL SYSTEM



TOP VIEW

① ASSEMBLY

---

 SWINGMASTER CORPORATION

PARTS BOOK

---

 MACHINE

SECTION

14

---

 MODEL 181 SWINGLOADER

---

 COVERS AND GRILL
 

---

 ASSEMBLY  
 NUMBER
 

---

DESCRIPTION

1800276

---

 FUEL LEVEL SENDER
 

---

ITEM NO.	PART NUMBER	DESCRIPTION	QTY. USED
2	8700742	BRASS FLOAT	1

---