


SECTION B

DRIVE
SYSTEM



TOLERANCES

UNLESS OTHERWISE SPECIFIED
FRACTIONS $\pm$ /-
3 PLACE DECIMALS $\pm$ /-
2 PLACE DECIMALS $\pm$ /-
1 PLACE DECIMALS $\pm$ /-
ANGLES

SEE SWINGMASTER SPECIFICATION
0-1 FOR TOLERANCES NOT SPECIFIED

DIMENSIONS ARE IN INCHES
DO NOT SCALE DRAWING
SCALE: 1=5

SWINGMASTER CORPORATION

730 INDUSTRIAL DRIVE
ELMURST, ILLINOIS 60120

ENGINE/TORQUE CONVERTER INSTALLATION

WITH CUMMINS QSB6.7 DIESEL ENGINE

MODEL 361 & SL180

DRAWN BY: J.K.

DATE: 3-14-07

DRAWING NO.


D1-886

MACHINE	SECTION	2

MODEL SL180 SWINGLOADER	DRIVE SYSTEM	

ASSEMBLY		DESCRIPTION	QTY
NUMBER			
-----		-----	-----
1806704		ENGINE AND TORQUE CONVERTER INST'L	

ITEM	PART	DESCRIPTION	QTY
NO.	NUMBER		USED
-----			-----
2	1806706	CUMMINS QSB6.7 DIESEL ENGINE	1
3	1802040	TORQUE CONVERTER MODEL C-273.5	1
4	1806155	H.H.C.S.	32
5	1805552	H.H.C.S. M-16X2.00X70MM	1
6	1801566	H.H.C.S. 5/8-11 X 3 1/2" LONG	2
7	1801363	ESNA HEX NUT 5/8-11	2
8	1806685	REAR ENGINE MTG. BRACKET	2
9	1802043	M-10 LOCK WASHER	12
10	1803484	M-12 LOCK WASHER	8
11	1803486	H.H.C.S. M*10-1.50 X 30MM LONG	12
12	1803704	H.H.C.S. M*12-1.75 X 60MM LONG	8
13	1803488	CENTER BONDED MOUNT - FOR 5/8" BOLT	3
14	1803489	TAIL WASHER - 2 1/2" OD X 5/8" ID	3
15	1803490	HEAD WASHER - 2 3/4" OD X 5/8" ID	2



① INSTALLATION


TOLERANCES UNLESS OTHERWISE SPECIFIED FRACTIONS $\pm$ 3 PLACE DECIMALS $\pm$ 2 PLACE DECIMALS $\pm$ 1 PLACE DECIMALS $\pm$ ANGLES SEE SWINGMASTER SPECIFICATION 0-1 FOR TOLERANCES NOT SPECIFIED DIMENSIONS ARE IN INCHES DO NOT SCALE DRAWING SCALE: 1=0	SWINGMASTER CORPORATION 11415 MELROSE AVENUE FRANKLIN PARK, ILLINOIS 60151	
	DRIVESHAFT INSTALLATION	
	MODEL SL180	
	WITH CUMMINS QSB 6.7 DIESEL ENGINE	
DRAWN BY: JJC DATE: 6-29-07	DRAWING NO.	D2-789

MECHINE	SECTION	2


MODEL SL180 SWINGLOADER	DRIVE SYSTEM	

ASSEMBLY NUMBER		DESCRIPTION	
-----		-----	
1806733		DRIVESHAFT INSTALLATION	

ITEM NO.	PART NUMBER	DESCRIPTION	QTY USED
-----		-----	-----
2	1800217	DRIVE SHAFT - TRANSMISSION TO AXLE	1
3	1803418	DRIVESHAFT - AXLE TO TRANSMISSION	1
4	1803419	DRIVESHAFT - ENGINE TO TRANSMISSION	1
5	1800458	H.H.C.S. 3/8-24 X 1 3/4" LONG	8
6	1800474	H.H.C.S. 1/2-20 X 2 1/4" LONG	16



← FRONT OF MACHINE



① INSTALLATION

TOLERANCES		SWINGMASTER CORPORATION	
UNLESS OTHERWISE SPECIFIED		11415 MELORE AVENUE	
FRACTIONS +/-		FRANKLIN PARK, ILLINOIS 60131	
3 PLACE DECIMALS +/-		AXLE INSTALLATION	
2 PLACE DECIMALS +/-		MODEL SL180-15	
1 PLACE DECIMALS +/-		DRAWN BY: J.K.	
ANGLES		DATE: 7-16-98	
SEE SWINGMASTER SPECIFICATION		DRAWING NO.	
C-1 FOR TOLERANCES NOT SPECIFIED		D-790	
DIMENSIONS ARE IN INCHES			
DO NOT SCALE DRAWING			
SCALE: 1/2"=1'			

MACHINE

SECTION

2

MODEL SL180 SWINGLOADER

DRIVE SYSTEM

ASSEMBLY



NUMBER

DESCRIPTION

1805771

AXLE INSTALLATION - DISC BRAKE

ITEM NO.	PART NUMBER	DESCRIPTION	QTY. USED
002	1805755	AXLE ASSEMBLY - MODEL DB-102	2.00
003	1800429	H.H.C.S. 7/8-14 X 8 1/2" LONG	12.00
004	1800536	ESNA THICK HEX NUT 7/8-14	16.00
005	1800662	90 DEG 1/8" PIPE-M GREASE FITTING	2.00
006	1800325	SHAFT LOCK PLATE	2.00
007	1800452	H.H.C.S. 3/8-16 X 1" LONG	4.00
008	1800568	3/8" LOCK WASHER	4.00
009	1802015	2.00" DIA. PIN X 5 7/8" LONG	2.00
010	1802012	2.00" I.D. STEEL BUSHING	2.00
011	1805772	AXLE CRADLE	1.00
012	1801148	H.H.C.S. 7/8-14 X 10" LONG	4.00
013	1800560	7/8" FLAT WASHER	4.00



① ASSEMBLY

RATIOS	
CARRIER	5.57
PLANET	3.00
TOTAL	16.71

RECOMMENDED LUBRICANTS (SPEC. MIL-L-2105-C).
 QUANTITY: 10.5 QUARTS IN DIFFERENTIAL BOWL.
 ABOVE 0° F: GEAR LUBE 85W-140
 -40° TO +50° F: GEAR LUBE 80W-140
 BELOW -40° F: GEAR LUBE 75W
 ITEM ⑩A CONVERTS FROM 2007 SERIAL NUMBER.

TOLERANCES
 UNLESS OTHERWISE SPECIFIED
 FRACTIONS +/-
 3 PLACE DECIMALS +/-
 2 PLACE DECIMALS +/-
 1 PLACE DECIMALS +/-
 ANGLES
 SEE SWINGMASTER SPECIFICATION
 0-1 FOR TOLERANCES NOT SPECIFIED
 DIMENSIONS ARE IN INCHES
 DO NOT SCALE DRAWING
 SCALE: 1"=1"

SWINGMASTER CORPORATION

11415 MELROSE AVENUE
 FRANKLIN PARK, ILLINOIS 60131

AXLE ASSEMBLY

MODEL DB-102 AXLE

MODEL 361 & 182

DRAWN BY: J.K.

DATE: 2-19-97

DRAWING NO.

D4-52

REV	DATE	DESCRIPTION	ENG. NO.	BY
1	2-9-07	ITEM ⑩A REPLACE FOR ⑩	2007001	J.K.

MACHINE

SECTION

2

MODEL 361 SWINGLOADER

DRIVE SYSTEM


ASSEMBLY
NUMBER

DESCRIPTION

1805755

AXLE ASSEMBLY - MODEL DB-102

ITEM NO.	PART NUMBER	DESCRIPTION	QTY. USED
002	1800002	BEARING CAP (STEERING AXLE)	2.00
003	1800003	BEARING CAP (STEERING AXLE)	2.00
005	1800005	PIN	2.00
006	1800006	STEERING TIE ROD ASSEMBLY	1.00
007	1800007	COTTER PIN 1/4 X 2" LONG	2.00
008	1800663	STRAIGHT 1/8" MALE-PIPE GREASE FITTING	2.00
009	1802433	RIBBED AXLE HOUSING WITH CYLINDER LUGS	1.00
10A	1806678	AXLE U-JOINT SHAFT - 361	2.00
010	1800195	AXLE SHAFT	0.00
10A	1806678	AXLE U-JOINT SHAFT - 361	2.00
011	1800011	WHEEL MOUNTING STUD R/H	24.00
012	1800012	CAP NUT 3/4 - 16	24.00
013	1800535	GRIPCO HEX NUT 3/4-16	24.00
015	1805756	AXLE PLANETARY END ASSEMBLY	2.00
016	1800016	1" PIPE PLUG-SOCKET HEAD	1.00
017	1800017	1/2" PIPE PLUG-HEX HEAD	1.00
018	1800018	1 1/4" PIPE PLUG-HEX HEAD	1.00
019	1800019	1/8" PIPE-M RELIEF FITTING 1MIN-5MAX PSI	1.00
020	1804359	OIL SEAL	2.00
021	1804349	DIFFERENTIAL ASSEMBLY	1.00
022	1800022	5/8" LOCK WASHER	20.00
023	1800023	H.H.C.S. 5/8-11 X 1 3/4" LONG	12.00



NOTE:
ITEM 31A REPLACED FOR ITEM 31
FROM 2007 SERIAL NUMBER

LUBRICATE & TIGHTEN WITH TORQUE SPECIFIED IN SA FICKLE

ITEM	INCH OR MM TORQUE
31	200-220
32	120-141
33	210-230
34	210-230
35	210-230

USE LOCTITE ON THESE NUTS.

TOLERANCES UNLESS OTHERWISE SPECIFIED FRACTIONS +/- 3 PLACE DECIMALS +/- 2 PLACE DECIMALS +/- 1 PLACE DECIMALS +/- ANGLES SEE SWINGMASTER SPECIFICATION 0-1 FOR TOLERANCES NOT SPECIFIED DIMENSIONS ARE IN INCHES DO NOT SCALE DRAWING SCALE: NONE	SWINGMASTER CORPORATION 11415 MELROSE AVENUE FRANKLIN PARK, ILLINOIS 60131	
	PLANETARY END ASSEMBLY	
	MODEL DB-102 AXLE	
	MODEL 361 & 182	
DRAWN BY: J.K. DATE: 1-28-96	DRAWING NO. D4-51	

1	2-9-07	31A REPLACED FOR (31)	2007002	J.K.
REV	DATE	DESCRIPTION	ENG. NO.	BY

MACHINE	SECTION	2
MODEL 361 SWINGLOADER	DRIVE SYSTEM	

ASSEMBLY
NUMBER

DESCRIPTION

1805756

AXLE PLANETARY END ASSEMBLY

ITEM NO.	PART NUMBER	DESCRIPTION	QTY. USED
002	1804356	SUN GEAR	1.00
003	1800027	PLANET GEAR	4.00
004	1800028	NEEDLE BEARING - 1-1/4" ID	8.00
005	1800029	1 9/32" BRASS FLAT WASHER	8.00
006	1800030	1 25/32" BRASS FLAT WASHER	1.00
007	1800031	GEAR PIN (PLANET END ASSEMBLY)	4.00
008	1804358	BUSHING	1.00
009	1800033	BEARING CONE 4-1/4" BORE	1.00
010	1800034	BEARING CUP 4-1/4" BORE	1.00
011	1805591	WHEEL HUB	1.00
012	1800036	SHAFT SEAL 5-1/4" SHAFT	1.00
013	1803539	WHEEL SPINDLE	1.00
014	1800038	BEARING CONE 4" BORE	1.00
015	1800039	BEARING CUP 4" BORE	1.00
016	1800040	GASKET - ROUND, 12-HOLE	1.00
017	1800041	PLANET END COVER	1.00
018	1800042	BALL SOCKET	1.00
019	1800043	SHAFT SEAL 5" SHAFT	1.00
020	1800044	BALL BEARING - UNSHIELDED, SINGLE ROW	1.00
021	1804357	OIL SEAL	1.00
022	1800046	PLANET CARRIER	1.00
023	1800047	PLANET GEAR CARRIER PLATE ASSY W/O HOLES	1.00
024	1800048	ANNULUS RING GEAR	1.00
025	1800049	3.525" SNAP RING	1.00
026	1800050	R/H THREAD STUD 7/8-14 X 4" LONG	1.00
027	1800051	1.771" SNAP RING	1.00
028	1800052	SLOTTED HEX NUT 1-14	4.00
029	1800053	H.H.C.S. 3/4-16 X 2 1/4" LONG	5.00
030	1800054	R/H THREAD STUD 7/8-14 X 3 3/4" LONG	4.00
031	1804355	RZEPPA JOINT	0.00
31A	1806674	RZEPPA UNIVERSAL JOINT ASS'T	1.00

MACHINE

SECTION

2

MODEL 361 SWINGLOADER

DRIVE SYSTEM


ASSEMBLY
NUMBER

DESCRIPTION

1805756

AXLE PLANETARY END ASSEMBLY

ITEM NO.	PART NUMBER	DESCRIPTION	QTY. USED
032	1800056	1" FLAT WASHER	4.00
033	1800019	1/8" PIPE-M RELIEF FITTING 1MIN-5MAX PSI	1.00
034	1800058	GASKET - ROUND, 12-HOLE	1.00
035	1801924	AXLE BALL JOINT HOUSING ASSEMBLY	1.00
036	1800059	65 DEG 1/8" PIPE-M GREASE FITTING	2.00
037	1805592	SPINDLE MOUNTING SHOULDER BOLT 5/8-18	12.00
038	1800061	H.H.C.S. 5/16-18 X 7/8" LONG	12.00
039	1805595	DISC BRAKE ASSEMBLY(6)	2.00
040	1800022	5/8" LOCK WASHER	8.00
041	1800064	COTTER PIN 3/16 X 2" LONG	4.00
042	1800065	H.H.C.S. 5/8-18 X 3 3/4" LONG	8.00
043	1800066	SOCKET HEAD CAP SCREW 5/8-18 X 3" LG.	4.00
044	1800067	3/8" PIPE PLUG-HEX HEAD	1.00
045	1800068	1/8" PIPE PLUG-HEX HEAD	1.00
046	1800069	SPINDLE LOCK NUT	1.00
047	1800538	THICK HEX NUT 7/8-14	13.00
048	1800071	SEAL, BALL SOCKET	1.00
049	1800072	AXLE BALL SEAL RETAINER	1.00
050	1800073	H.H.C.S. 1/4-28 X 3/4" LONG	8.00
051	1800074	5/16" LOCK WASHER	12.00
052	1800075	BEARING CONE 1-3/4" BORE	2.00
053	1800076	BEARING CUP 1-3/4" BORE	2.00
054	1805593	SPINDLE MOUNTING SHOULDER BOLT 5/8-18	0.00
055	1800078	R/H THREAD STUD 7/8-14 X 3 1/2" LONG	8.00
056	1805594	HEX HEAD CAP SCREW 5/8-18X1-3/4"LG	16.00
057	1800080	SPECIAL 11/16 FLAT WASHER	12.00
058	1800081	SHIM - 0.002" (STRG. AXLE BEARING)	1.00
059	1800082	SHIM - 0.005" (STRG. AXLE BEARING)	1.00
060	1800083	SHIM - 0.010" (STRG. AXLE BEARING)	1.00
061	1800084	BEARING LOCKWASHER	1.00
062	1805636	BRAKE DISC	1.00





① INSTALLATION

TOLERANCES		SWINGMASTER CORPORATION	
UNLESS OTHERWISE SPECIFIED		11415 MELORE AVENUE	
FRACTIONS +/-		FRANKLIN PARK, ILLINOIS 60131	
3 PLACE DECIMALS +/-		TRANSMISSION INSTALLATION	
2 PLACE DECIMALS +/-			
1 PLACE DECIMALS +/-		MODEL 361 & SL180	
ANGLES		DRAWN BY: J.K.	
SEE SWINGMASTER SPECIFICATION		DATE: 7-11-97	
G-1 FOR TOLERANCES NOT SPECIFIED		DRAWING NO.	
DIMENSIONS ARE IN INCHES		D-735	
DO NOT SCALE DRAWING			
SCALE: 1=3			

MACHINE	SECTION	2
MODEL SL180 SWINGLOADER	DRIVE SYSTEM	

ASSEMBLY NUMBER	DESCRIPTION
1805738	TRANSMISSION INSTALL

ITEM NO.	PART NUMBER	DESCRIPTION	QTY. USED
002	1802018	TRANSMISSION - R28662	1.00
003	1800479	H.H.C.S. 3/4-10 X 2" LONG	8.00
004	1800572	3/4" LOCK WASHER	8.00
005	1805753	FRONT LEFT TRANS. MOUNTING BRACKET	1.00
006	1805330	FRONT RIGHT TRANS. MTG. BRACKET	1.00
007	1805332	REAR LEFT TRANS. MTG. BRACKET	1.00
008	1805331	REAR RIGHT TRANS. MTG. BRACKET	1.00
009	1802023	H.H.C.S. 3/4-10 X 3" LONG	4.00
010	1800522	ESNA HEX NUT 3/4-10	4.00
011	1800557	3/4" FLAT WASHER	8.00



1- ASSY.

MACHINE

SECTION

2

MODEL 361 SWINGLOADER

DRIVE SYSTEM


ASSEMBLY
NUMBER

DESCRIPTION

1800006

STEERING TIE ROD ASSEMBLY

ITEM NO.	PART NUMBER	DESCRIPTION	QTY. USED
2	1800087	TIE ROD	1
3	1800088	TIE ROD END YOKE ASSY (INCLUDES ITEMS 3A+B)	2
3A	1800098	BRONZE BUSHING (NOT SHOWN IN PICTURE)	2
3B	1800099	TIE ROD END (NOT SHOWN IN PICTURE)	2
4	1800089	H.H.C.S. 1/2-20 X 3" LONG	4
5	1800530	ESNA HEX NUT 1/2-20	4



MACHINE

SECTION

2

MODEL 361 SWINGLOADER

DRIVE SYSTEM

ASSEMBLY
NUMBER

DESCRIPTION

BALL SOCKET HOUSING ASSEMBLY
(PART OF 1803537 PLANETARY END ASSEMBLY)
(PART OF 1804509 PLANETARY END ASSEMBLY)

ITEM NO.	PART NUMBER	DESCRIPTION	QTY. USED
6	1800538	HEX NUT 7/8-14	13
7	1800078	R/H THREAD STUD 7/8-14 X 3 1/2" LONG	8
8	1800003	BEARING CAP - TOP	1
8A	1800002	BEARING CAP - BOTTOM	1
9	1800663	STRAIGHT 1/8" PIPE-M GREASE FITTING	2
10	1801924	AXLE BALL JOINT HOUSING ASSEMBLY	1
10A	1800065	H.H.C.S. 5/8-18 X 3 3/4" LONG	8
10A	1800022	5/8" LOCK WASHER	8
10A	1800066	SOCKET HEAD CAP SCREW 5/8-18 X 3" LONG	4
11	1800071	SEAL, BALL SOCKET	1
12	1800072	AXLE BALL SEAL RETAINER	1
13	1800073	H.H.C.S. 1/4-28 X 3/4" LONG	8
14	1800076	BEARING CUP 1-3/4" BORE	2
15	1800075	BEARING CONE 1-3/4" BORE	2
17	1800042	BALL SOCKET HOUSING	1
30	1800053	H.H.C.S. 3/4-16 X 2 1/4" LONG	5
31	1800050	R/H THD STUD 7/8-14 X 4" LG (CENTER ONLY)	1
32	1800054	R/H THREAD STUD 7/8-14 X 3 3/4" LONG	4
33	1800081	SHIM - 0.002" THICK	A.R.
34	1800082	SHIM - 0.005" THICK	A.R.
35	1800083	SHIM - 0.010" THICK	A.R.

MACHINE	SECTION	2
MODEL 361 SWINGLOADER	DRIVE SYSTEM	
MODEL 180 SWINGLOADER		


ASSEMBLY NUMBER		DESCRIPTION	
1806674		RZEPPA UNIVERSAL JOINT ASS'Y	
ITEM NO.	PART NUMBER	DESCRIPTION	QTY USED
002	1806675	RZEPPA UNIVERSAL JOINT WELDMENT	1
003	1806676	SHAFT	1
004	1806671	U-JOINT	1
005	1806821	CROSS BEARING	1
006	1806822	RETAINING RING	4

NOTE :
SPLINE TOLERANCES MUST
CONFORM TO S.A.E. STANDARDS.


MAJOR DIA CHAMFER HEIGHT : 0.006 MIN
MAJOR DIA CHAMFER DIMENSION : .0005

MINOR DIA FILLET RADIUS : 0.006
MINOR DIA FILLET HEIGHT : 0.004

C1-21



TOLERANCES		SWINGMASTER CORPORATION	
UNLESS OTHERWISE SPECIFIED		730 INDUSTRIAL DRIVE	
FRACTIONS +/-		ELMHURST, ILLINOIS 60126	
3 PLACE DECIMALS +/-		RZEPPA UNIVERSAL JOINT ASSEMBLY	
2 PLACE DECIMALS +/-		FOR MODEL 361 & SL180	
1 PLACE DECIMALS +/-			
ANGLES			
SEE SWINGMASTER SPECIFICATION			
G-1 FOR TOLERANCES NOT SPECIFIED			
DIMENSIONS ARE IN INCHES		DRAWN BY: J.K.	
DO NOT SCALE DRAWING		DATE: 2-5-07	
SCALE: 1/2		DRAWING NO.	
		C1-21N	



MACHINE	SECTION	2
MODEL 361 SWINGLOADER	DRIVE SYSTEM	

ASSEMBLY
NUMBER

DESCRIPTION


1800055

RZEPPA UNIVERSAL JOINT

1804355

RZEPPA UNIVERSAL JOINT

ITEM NO.	PART NUMBER	DESCRIPTION	QTY. USED
		FOR 1800055 RZEPPA UNIVERSAL JOINT FOR MACHINE SERIAL NUMBERS 88361L0001 TO 90361L0006	
2	8700973	OUTER RACE	1
3	8700975	CAGE	1
4	8700974	BALL	6
5	8700976	INNER RACE	1
		FOR 1804355 RZEPPA UNIVERSAL JOINT FOR MACHINE SERIAL NUMBERS 91361L0007 TO CURRENT	
2	8703618	OUTER RACE	1
3	8703619	CAGE	1
4	8703620	BALL	6
5	8703621	INNER RACE	1



MACHINE

SECTION

2

MODEL 361 SWINGLOADER

DRIVE SYSTEM

ASSEMBLY
NUMBER

DESCRIPTION

1800021*

DIFFERENTIAL CARRIER - MODEL DS-101 AXLE




1804349**

DIFFERENTIAL CARRIER - MODEL DS-102 AXLE

ITEM NO.	PART NUMBER	DESCRIPTION	QTY. USED
1A	8700977	RIGHTHAND DIFFERENTIAL BEARING ADJUSTER	1
1B	8700978	LEFTHAND DIFFERENTIAL BEARING ADJUSTER	1
2A	8700979	RIGHTHAND DIFFERENTIAL BEARING CUP	1
2B	8700980	LEFTHAND DIFFERENTIAL BEARING CUP	1
3A	8700981	RIGHTHAND DIFFERENTIAL BEARING CONE	1
3B	8700982	LEFTHAND DIFFERENTIAL BEARING CONE	1
4	8701080	WHEEL DIFFERENTIAL CASE KIT INCLUDES ITEMS 4A, 4B, AND 5	1
5	8701079	DIFFERENTIAL CASE CAP SCREW	12
6a*	8701081	DIFFERENTIAL SIDE GEAR	2
6b**	8703622	DIFFERENTIAL SIDE GEAR	2
7	8701082	SIDE GEAR THRUST WASHER	2
8	8701083	SIDE PINION THRUST WASHER	4
9	8701084	SIDE PINION	4
10	8701085	SPIDER	1
	8701086	WHEEL DIFFERENTIAL SIDE GEAR & PINION KIT INCLUDES ITEMS 6-10	1
11A&B	8702822	RING AND PINION GEAR SET	1
12A	8701089	RING GEAR BOLT	16
12B	8701090	RING GEAR NUT	16

* FOR MACHINE SERIAL NUMBERS 88361L0001 TO 90361L0006

** FOR MACHINE SERIAL NUMBERS 91361L0007 TO CURRENT



MACHINE

SECTION

2

MODEL 361 SWINGLOADER

DRIVE SYSTEM

ASSEMBLY
NUMBER

DESCRIPTION




1800021*


DIFFERENTIAL CARRIER - MODEL DS-101 AXLE

1804349**

DIFFERENTIAL CARRIER - MODEL DS-102 AXLE

ITEM NO.	PART NUMBER	DESCRIPTION	QTY. USED
13A		RIGHTHAND BEARING CAP	1
13B		LEFTHAND BEARING CAP	1
13C		DIFFERENTIAL CARRIER	1
		ITEM 13A,B,C ARE UNAVAILABLE SEPERATELY	
14	8701095	BEARING CAP SCREW	4
15	8701096	FLAT WASHER	4
16	8701097	LOCKWIRE	4
	8701094	DIFFERENTIAL CARRIER & BEARING CAP ASSY INCLUDES ITEMS 13-16	1
17	8701098	RIGHTHAND BEARING ADJUSTER LOCK	1
18	8701099	RIGHTHAND BEARING ADJUSTER COTTER PIN	1
19	8701100	LEFTHAND BEARING ADJUSTER LOCK	1
20	8701101	LEFTHAND BEARING ADJUSTER COTTER PIN	1
21	8701102	PINION PILOT BEARING	1
23	8701103	PINION BEARING CONE	2
24	8701115	PINION BEARING SPACER	AR
25	8701104	PINION BEARING CAGE	1
26	8701105	PINION BEARING CUP (INNER & OUTER)	2
	8701106	PINION BEARING CAGE AND CUP ASSEMBLY INCLUDES ITEMS 25, 26	1
27	8701116	PINION BEARING CAGE SHIM	AR
28	8701107	BEARING CAGE CAP SCREW	6
29	8701114	LOCKWASHER	6
30	8701108	OIL SEAL & RETAINER	1





1 INSTALLATION

TOLERANCES

UNLESS OTHERWISE SPECIFIED

FRACTIONS +/-
3 PLACE DECIMALS +/-
2 PLACE DECIMALS +/-
1 PLACE DECIMALS +/-
ANGLES

SEE SWINGMASTER SPECIFICATION
G-1 FOR TOLERANCES NOT SPECIFIED

DIMENSIONS ARE IN INCHES
DO NOT SCALE DRAWING
SCALE: NONE

SWINGMASTER CORPORATION

11415 MELROSE AVENUE
FRANKLIN PARK, ILLINOIS 60131

TRANSMISSION - TORQUE CONVERTER

LINES & FITTINGS INSTALLATION

DRAWN BY: J.K.

DATE: 7-15-01


DRAWING NO.

H4-179

MECHINE	SECTION	2
MODEL SL180 SWINGLOADER	DRIVE SYSTEM	

ASSEMBLY NUMBER	DESCRIPTION
1806680	TRANS./ TORQUE CONVERTER LINES & FITTINGS

ITEM NO.	PART NUMBER	DESCRIPTION	QTY USED
2	1802822	HOSE ASSEMBLY 1503-12	1
3	1802520	HOSE ASSEMBLY 1503-12	1
4	1802323	HOSE ASSEMBLY 1503-16	2
5	1805742	HOSE ASSEMBLY	1
6	1805743	HOSE ASSEMBLY	1
7	1802523	HOSE ASSEMBLY 1503-8	1
8	1802524	TRANSMISSION OIL FILTER	1
10	1800568	3/8" LOCK WASHER	4
11	1800760	STRAIGHT MALE 1 PIPE TO 1 TUBE	1
12	1800765	STRAIGHT MALE 1/2 O-RING TO 1/2 TUB	1
13	1802346	STRAIGHT MALE 1 O-RING TO 3/4 TUBE	1
14	1800774	STRAIGHT MALE 1 O-RING TO 1 TUBE	1
15	1802525	STRAIGHT MALE 1 1/4 O-RING TO 1 TUB	1
16	1800791	90 DEG MALE ELBOW 1 PIPE TP 1 TUBE	1
17	1800801	90 DEG MALE ELBOW 3/4 O-RING TO 3/4	4
18	1800856	45 DEG TUBE ELBOW 1 M TO 1 F SWIVEL	1
19	1801034	45 DEG MALE ELBOW 1/2 TUBE TO 1/2 O	1
20	1804959	CONNECTOR	1
21	1800770	STRAIGHT MALE 3/4 O-RING TO 3/4 TUB	1
22	1800790	90 DEG MALE ELBOW 1 PIPE TO 3/4 TUB	1



① ASSEMBLY

SWINGMASTER CORPORATION

PARTS BOOK

MACHINE

SECTION

2

MODEL 361 SWINGLOADER

DRIVE SYSTEM

ASSEMBLY
NUMBER

DESCRIPTION

1802524

TRANSMISSION OIL FILTER ASSEMBLY

ITEM NO.	PART NUMBER	DESCRIPTION	QTY. USED
2	8701990	FILTER HEAD & BY-PASS VALVE ASSEMBLY	1
3	8701991	FILTER CAN SEALING RING	1
4	8701992	FILTER CAN ASSEMBLY INCLUDES ITEMS 6 & 7	1
5	8701993	FILTER ELEMENT	1
6	8701994	BOLT SEAL GASKET	1
7	8701995	SEALING WASHER	1

MACHINE	SECTION	B
-----	-----	-----
SWINGLOADER	DRIVE SYSTEM	
-----	-----	-----

TORQUE CONVERTER ASSEMBLY

DESCRIPTION


PRESSURE REGULATING VALVE GROUP
CONVERTER HOUSING AND OIL BAFFLE GROUP
13.5" WHEEL GROUP
RING GEAR MOUNTING GROUP
STATOR SUPPORT GROUP
TURBINE SHAFT AND OUTPUT SHAFT GROUP
CHARGING PUMP GROUP
PUMP DRIVE GROUP
PUMP ADAPTER GROUP

PART NUMBER	DESCRIPTION
-----	-----
8702143	TORQUE CONVERTER GASKET & SEALING KIT
-----	-----

CLARK

CLARK

PRESSURE REGULATING VALVE



SWINGMASTER CORPORATION

PARTS BOOK

MACHINE

SECTION

2

SWINGLOADER

DRIVE SYSTEM

ASSEMBLY
NUMBER

DESCRIPTION

1802040


TORQUE CONVERTER ASSEMBLY
- PRESSURE REGULATING VALVE GROUP

ITEM NO.	PART NUMBER	DESCRIPTION	QTY. USED
1	8700036	VALVE STOP	1
2	8700135	VALVE STOP O-RING	1
3	8700037	VALVE STOP ROLL PIN	1
4	8700057	CAP SCREW & LOCK WASHER	4
5		SEE ITEM 4	
6	8700037	VALVE STOP ROLL PIN	1
7	8702109	VALVE SPRING - OUTER	1
8	8702110	VALVE SPRING - INNER	1
9	8700043	VALVE PISTON	1
10	8700037	VALVE STOP O-RING	1
11	8700036	VALVE STOP	1
12	8700029	GASKET	1
13	8700030	O-RING	1
14	8700031	VALVE SPRING	1
15	8700032	VALVE PLUNGER	1
16	8700033	VALVE SEAT	1
17	8700034	PIPE PLUG	1
18	8700034	PIPE PLUG	1
19	8702111	REGULATOR VALVE ASSEMBLY	1

CLARK

CLARK

CONVERTER HOUSING & OIL BAFFLE GROUP



MACHINE	SECTION	2
-----	-----	-----
SWINGLOADER	DRIVE SYSTEM	
-----	-----	-----

ASSEMBLY
NUMBER


DESCRIPTION

1802040-----
TORQUE CONVERTER ASSEMBLY
- CONVERTER HOUSING & OIL BAFFLE GROUP

ITEM NO.	PART NUMBER	DESCRIPTION	QTY. USED
1	8702112	OIL BAFFLE - INCLUDES ITEM 3	1
2	8700081	O-RING	1
3	8702113	OIL BAFFLE OIL SEAL	1
4		NOT USED ON THIS MODEL	
5	8700080	CONVERTER HOUSING	1
6	8700058	PIPE PLUG	4
7	8700059	PIPE PLUG	1
8	8700060	LOCK WASHER	3
9	8700061	CAP SCREW	3
10	8700034	PIPE PLUG	1
-----	-----	-----	-----

CLARK

CLARK



MACHINE	SECTION	2
-----	-----	-----
SWINGLOADER	DRIVE SYSTEM	
-----	-----	-----

ASSEMBLY
NUMBER

DESCRIPTION

1802040


TORQUE CONVERTER ASSEMBLY
- 13.5" WHEEL GROUP

ITEM NO.	PART NUMBER	DESCRIPTION	QTY. USED
1	8702114	TURBINE HUB	1
2	8702115	TURBINE HUB RETAINING RING	1
3	8702116	REACTION MEMBER SNAP RING	1
4	8702117	REACTION MEMBER	1
5	8702118	REACTION MEMBER SPACER	1
6	8700095	BEARING SNAP RING	1
7	8702119	IMPELLER HUB BEARING	1
8	8702120	IMPELLER HUB	1
9	8702121	IMPELLER HUB O-RING	1
10	8702122	IMPELLER	1
11	8702123	WASHER	8
12	8702124	CAP SCREW	8
13	8702125	IMPELLER COVER SLEEVE	1
14	8702126	IMPELLER COVER	1
15	8702127	IMPELLER COVER BEARING	1
16	8702128	BEARING SNAP RING	1
17	8700112	O-RING	1
18	8700108	CAP SCREW	1
19	8702129	WASHER	8
20	8702130	TURBINE	1
21	8702115	TURBINE HUB RETAINING RING	1
22		SEE ITEM 23	
23	8700057	CAP SCREW & LOCK WASHER	24
24		NOT USED ON THIS MODEL	
25		NOT USED ON THIS MODEL	

CLARK

CLARK

RING GEAR MOUNTING GROUP



SWINGMASTER CORPORATION

PARTS BOOK

MACHINE	SECTION	2
-----	-----	-----
SWINGLOADER	DRIVE SYSTEM	
-----	-----	-----

ASSEMBLY
NUMBER

DESCRIPTION

1802040-----
TORQUE CONVERTER ASSEMBLY
- RING GEAR MOUNTING GROUP


ITEM NO.	PART NUMBER	DESCRIPTION	QTY. USED
1	8702133	RING GEAR	1
2		NOT USED ON THIS MODEL	
3	8702135	SELF LOCKING CAP SCREW	32
4	8700026	BREATHING ASSEMBLY	1
5	8702134	BACKING RING - NOT SHOWN IN PICTURE	1
	8702132	RING GEAR KIT - INCLUDES ITEMS 1 & 3	1

*clark no**802651**236936*

CLARK

CLARK

STATOR SUPPORT GROUP



SWINGMASTER CORPORATION

PARTS BOOK

MACHINE

SECTION

2

SWINGLOADER

DRIVE SYSTEM

ASSEMBLY
NUMBER

DESCRIPTION

1802040


TORQUE CONVERTER ASSEMBLY
- STATOR SUPPORT GROUP

ITEM NO.	PART NUMBER	DESCRIPTION	QTY. USED
1	8702136	STATOR SUPPORT PISTON RING	1
2	8702137	PISTON RING EXPANDER SPRING	1
3	8702138	STATOR SUPPORT & SLEEVE ASSEMBLY	1
4	8700090	LOCK WASHER	6
5	8700089	CAP SCREW	6

CLARK

CLARK

TURBINE SHAFT & OUTPUT SHAFT GROUP



MACHINE	SECTION	2
-----	-----	-----
SWINGLOADER	DRIVE SYSTEM	
-----	-----	-----

ASSEMBLY
NUMBER

DESCRIPTION

1802040


TORQUE CONVERTER ASSEMBLY
- TURBINE SHAFT & OUTPUT SHAFT GROUP

ITEM NO.	PART NUMBER	DESCRIPTION	QTY. USED
1	8700078	BEARING SNAP RING	1
2	8700077	OUTPUT SHAFT FRONT BEARING	1
3	8700076	OUTPUT SHAFT GEAR (27 TEETH)	1
4	8700075	OUTPUT SHAFT	1
5	8700325	OUTPUT SHAFT BEARING SNAP RING	1
6	8700073	OUTPUT SHAFT REAR BEARING	1
7	8700072	BEARING RETAINER O-RING	1
8	8700070	BEARING RETAINER	1
9	8700158	BEARING RETAINER SCREW LOCK WASHER	3
10	8700064	BEARING RETAINER SCREW	3
11	8700065	OUTPUT SHAFT O-RING	1
12	8700066	OUTPUT SHAFT WASHER	1
13	8700065	OUTPUT SHAFT NUT	1
14	8700062	BEARING RETAINER OIL SEAL	1
15	8700069	BEARING RETAINER STUD NUT	2
16	8700158	BEARING RETAINER OIL LOCK WASHER	2
17	8700071	BEARING RETAINER STUD	2
18	8700097	GEAR SNAP RING	1
19	8700096	TURBINE SHAFT GEAR	1
20	8700095	TURBINE SHAFT SNAP RING	1
21	8700094	TURBINE SHAFT BEARING	1
22	8700092	TURBINE SHAFT PISTON RING	1
23	8702139	TURBINE SHAFT	1
24	8700068	OUTPUT FLANGE	1

CLARK

CLARK

CHARGING PUMP GROUP



MACHINE

SECTION

2

SWINGLOADER

DRIVE SYSTEM

ASSEMBLY
NUMBER

DESCRIPTION

1802040


TORQUE CONVERTER ASSEMBLY
- CHARGING PUMP GROUP

ITEM NO.	PART NUMBER	DESCRIPTION	QTY. USED
1	8702140	IMPELLER HUB GEAR	1
2	8702141	IMPELLER HUB GEAR SNAP RING	1
3	8700054	CHARGING PUMP SLEEVE	1
4	8700055	CHARGING PUMP GASKET	1
5	8702142	CONVERTER CHARGING PUMP	1
6	8700057	SCREW & LOCK WASHER (NOT AS SHOWN)	3
7		PART OF ITEM 6	
8		NOT USED ON THIS MODEL	

CLARK

CLARK

PUMP DRIVE GROUP



MACHINE	SECTION	2
-----	-----	-----
SWINGLOADER	DRIVE SYSTEM	
-----	-----	-----

ASSEMBLY NUMBER	DESCRIPTION
-----	-----
1802040	TORQUE CONVERTER ASSEMBLY - PUMP DRIVE GROUP
-----	-----

ITEM NO.	PART NUMBER	DESCRIPTION	QTY. USED
-----	-----	-----	-----
1	8700024	PUMP DRIVE GEAR SNAP RING	3
2	8700025	PUMP DRIVE GEAR (39 TEETH)	3
3	8700046	PUMP DRIVE SHAFT BEARING	3
4	8700047	PUMP DRIVE SHAFT SPACER	3
5	8700048	PUMP DRIVE SHAFT BEARING	3
6	8700049	PUMP DRIVE SHAFT BEARING SNAP RING	3
7	8700050	PUMP DRIVE SHAFT	3
8	8700051	PUMP DRIVE SHAFT SNAP RING	3
9	8700052	PUMP DRIVE WASHER	3
10	8700053	PUMP SHAFT SNAP RING	3
-----	-----	-----	-----

CLARK

CLARK




FIG. A.

DISCONNECT ASSEMBLY




FIG. B.

"A" SIZE TO "B" SIZE PUMP ADAPTOR




FIG. C.

"B" SIZE PUMP ADAPTOR




FIG. D.

FORWARD & REVERSE P.T.O.


R & HR 28000 SERIES - VARIOUS OPTIONS

MACHINE	SECTION	2
-----	-----	-----
SWINGLOADER	DRIVE SYSTEM	
-----	-----	-----

ASSEMBLY NUMBER	DESCRIPTION
-----	-----
1802040	TORQUE CONVERTER ASSEMBLY - PUMP ADAPTOR GROUP
-----	-----

ITEM NO.	PART NUMBER	DESCRIPTION	QTY. USED
-----	-----	-----	-----
		REFERENCE FIGURE C, FOR THE FOLLWING ITEMS FOR USE WITH HYDRAULIC PUMP 1800120 (SEE HYDRAULIC PUMP INSTALLATION IN SECTION 20)	
1	8700055	PUMP ADAPTOR GASKET	1
2	8700123	PUMP ADAPTOR	1
3	8700124	PUMP ADAPTOR SCREW LOCK WASHER	3
4	8700125	PUMP ADAPTOR SCREW	3
5		NOT USED ON THIS MODEL	
6		NOT USED ON THIS MODEL	

		REFERENCE FIGURE C, FOR THE FOLLOWING ITEMS FOR USE WITH HYDRAULIC PUMP 1800121 (SEE HYDRAULIC PUMP INSTALLATION IN SECTION 20)	
1	8700055	PUMP ADAPTOR GASKET	1
2	8700128	PUMP ADAPTOR (NOT AS SHOWN)	1
3		NOT USED ON THIS MODEL	
4	8700129	PUMP ADAPTOR SCREW	6
5		NOT USED ON THIS MODEL	
6		NOT USED ON THIS MODEL	
-----	-----	-----	-----



1 INSTALLATION

TOLERANCES		SWINGMASTER CORPORATION	
UNLESS OTHERWISE SPECIFIED FRACTIONS +/- 3 PLACE DECIMALS +/- 2 PLACE DECIMALS +/- 1 PLACE DECIMALS +/- ANGLES		11415 MELROSE AVENUE	
		FRANKLIN PARK, ILLINOIS 60131	
		TRANSMISSION OIL FILLER INSTALLATION	
		MODEL RTC-15 & SL180	
SEE SWINGMASTER SPECIFICATION G-1 FOR TOLERANCES NOT SPECIFIED DIMENSIONS ARE IN INCHES DO NOT SCALE DRAWING SCALE: NONE		DRAWN BY: J.K.	DRAWING NO.
		DATE: 7-20-98	H-283

MACHINE

SECTION

2

MODEL SL180 SWINGLOADER

DRIVE SYSTEM

ASSEMBLY
NUMBER

DESCRIPTION

1803835

TRANSMISSION OIL FILLER INSTALLATION

ITEM NO.	PART NUMBER	DESCRIPTION	QTY. USED
002	1800295	STEEL COUPLING - 3/4" x 1-5/8" LG.	1.00
003	1802671	3/4" PIPE PLUG - HEX HEAD	1.00
004	1803836	45 DEGREE MALE ELBOW 1" PIPE TO 3/4 TUBE	1.00
005	1803832	HOSE ASSEMBLY 2556-12	1.00

MACHINE

SECTION

B

SWINGLOADER

DRIVE SYSTEM

TRANSMISSION ASSEMBLY

DESCRIPTION

3 SPEED REMOTE CASE GROUP
TRANSMISSION CASE AND REAR GROUP
REVERSE AND HIGH SHAFT GROUP
FORWARD AND SECOND SHAFT GROUP
LOW SPEED SHAFT GROUP
IDLER SHAFT GROUP
OUTPUT SHAFT GROUP
HIGH AND LOW RANGE SHIFT CONTROL GROUP
SOLENOID CONTROL VALVE ASSEMBLY
DRIVE FLANGE

PART


NUMBER

DESCRIPTION

8702307 FRONT COVER & TRANSMISSION GASKET & SEALING KIT

CLARK

CLARK



MACHINE

SECTION

2

SWINGLOADER

DRIVE SYSTEM

ASSEMBLY
NUMBER

DESCRIPTION


1802018

TRANSMISSION ASSEMBLY
- 3 SPEED REMOTE CASE GROUP

ITEM NO.	PART NUMBER	DESCRIPTION	QTY. USED
1	8700166	INPUT FLANGE OIL SEAL	1
2	8700325	INPUT SHAFT FRONT BRG. RET. RING	1
3	8702144	INPUT SHAFT FRONT BEARING	1
4	8700325	INPUT SHAFT FRONT BRG. RET. RING	1
5	8700058	PIPE PLUG	1
6	8702145	FRONT COVER & TUBE ASSEMBLY INCLUDES ITEMS 7-12,14-17,22,23	1
7	8702146	O-RING	2
8	8702147	3RD SPEED TUBE ASSEMBLY	1
9	8702148	TUBE CLIP	2
10	8700155	TUBE CLIP SCREW LOCK WASHER	2
11	8700154	TUBE CLIP SCREW	2
12	8702149	REVERSE TUBE ASSEMBLY	1
13	8700169	BREATHER	1
14	8702150	FRONT COVER SLEEVE	2
15	8702151	FRONT COVER SLEEVE LOCK	2
16	8700155	SLEEVE LOCK SCREW LOCK WASHER	2
17	8700154	SLEEVE LOCK SCREW	2
18	8702152	INPUT SHAFT	1
19	8702153	INPUT SHAFT REAR BEARING	1
20	8702154	INPUT SHAFT GEAR	1
21	8700097	INPUT SHAFT GEAR RETAINER RING	1
22	8700134	TUBE SLEEVE	1
23	8700134	TUBE SLEEVE	1
24	8700148	PIPE PLUG	1
25	8702155	COVER TO CASE SCREW	4

CLARK

CLARK





MACHINE	SECTION	2
-----	-----	-----
SWINGLOADER	DRIVE SYSTEM	
-----	-----	-----

ASSEMBLY NUMBER	DESCRIPTION
-----	-----
1802018	TRANSMISSION ASSEMBLY
-----	- 3 SPEED REMOTE CASE GROUP


ITEM NO.	PART NUMBER	DESCRIPTION	QTY. USED
-----	-----	-----	-----
26	8700158	COVER TO CASE SCREW LOCK WASHER	4
27	8700184	FRONT COVER PLUG	1
28	8700186	FRONT COVER PLUG GASKET	1
29	8702156	COVER TO CASE SCREW	4
30	8700158	COVER TO CASE SCREW LOCK WASHER	4
31	8700064	COVER TO CASE SCREW	10
32	8700158	COVER TO CASE SCREW LOCK WASHER	10
33	8702157	FRONT COVER GASKET	1
34	8700189	FRONT COVER DOWEL PIN	2
-----	-----	-----	-----

CLARK

CLARK



CONVERTER HOUSING TO TRANSMISSION CASE SPACER USED ONLY WITH 12 PLATE CLUTCH PACK ASSEMBLY.



SPECIAL SUMP

MACHINE	SECTION	2
-----	-----	-----
SWINGLOADER	DRIVE SYSTEM	
-----	-----	-----

ASSEMBLY
NUMBER

DESCRIPTION

1802018

TRANSMISSION ASSEMBLY
- TRANSMISSION CASE & REAR GROUP

ITEM NO.	PART NUMBER	DESCRIPTION	QTY. USED
1	8702158	PRESSURE TUBE O-RING	1
2	8700134	PRESSURE TUBE SLEEVE	1
3	8702159	LOW SPEED CLUTCH PRESSURE TUBE	1
4	8702160	CASE TO COVER DOWEL PIN	2
5	8702161	CASE TO COVER GASKET	1
6	8702162	REAR COVER	1
7	8702163	CAP SCREW	21
8	8702164	LOCK WASHER	21
9	8702158	PRESSURE TUBE O-RING	1
10	8700134	PRESSURE TUBE SLEEVE	1
11	8702165	STUD	2
12	8702164	LOCK WASHER	2
13	8702167	NUT	2
14	8700145	REAR COVER PIPE PLUG	1
15	8700149	MAGNETIC DRAIN PLUG	1
16	8702168	OIL LEVEL PLUG	1
17	8702168	OIL LEVEL PLUG	1
18	8702169	SCREEN ASSEMBLY	1
19	8700186	SCREEN ASSEMBLY GASKET	1
20	8702170	TRANSMISSION CASE ASSEMBLY	1
		INCLUDES ITEMS 2,3,10,22-24,35-38	
21	8702171	TRANSMISSION CASE PLUG	1
22	8702172	SUCTION TUBE CLIP WASHER	1
23	8702173	SUCTION TUBE CLIP	1
24	8702174	SUCTION TUBE ASSEMBLY	1
25 THRU 34		NOT USED ON THIS MODEL	

MACHINE

SECTION


2

SWINGLOADER-----
DRIVE SYSTEM
-----ASSEMBLY
NUMBER
-----1802018
-----DESCRIPTION
-----TRANSMISSION ASSEMBLY
- TRANSMISSION CASE & REAR GROUP

ITEM NO.	PART NUMBER	DESCRIPTION	QTY. USED
35	8702175	RETAINING WASHER SCREW	2
36	8702176	RETAINING WASHER	1
37	8702177	SUCTION TUBE O-RING	1
38	8702178	SUCTION TUBE CLIP RIVET	1
39	8702179	OIL BAFFLE	1
40 THRU 43		NOT USED ON THIS MODEL	

CLARK

CLARK



MACHINE	SECTION	2
-----	-----	-----
SWINGLOADER	DRIVE SYSTEM	
-----	-----	-----

ASSEMBLY
NUMBER

DESCRIPTION


1802018

TRANSMISSION ASSEMBLY
- TRANSMISSION CASE & REAR GROUP




ITEM NO.	PART NUMBER	DESCRIPTION	QTY. USED
1	8702158	PRESSURE TUBE O-RING	1
2	8700134	PRESSURE TUBE SLEEVE	1
3	8702159	LOW SPEED CLUTCH PRESSURE TUBE	1
4	8702160	CASE TO COVER DOWEL PIN	2
5	8702161	CASE TO COVER GASKET	1
6	8702162	REAR COVER	1
7	8702163	CAP SCREW	21
8	8702164	LOCK WASHER	21
9	8702158	PRESSURE TUBE O-RING	1
10	8700134	PRESSURE TUBE SLEEVE	1
11	8702165	STUD	2
12	8702164	LOCK WASHER	2
13	8702167	NUT	2
14	8700145	REAR COVER PIPE PLUG	1
15	8700149	MAGNETIC DRAIN PLUG	1
16	8702168	OIL LEVEL PLUG	1
17	8702168	OIL LEVEL PLUG	1
18	8702169	SCREEN ASSEMBLY	1
19	8700186	SCREEN ASSEMBLY GASKET	1
20	8702170	TRANSMISSION CASE ASSEMBLY	1
		INCLUDES ITEMS 2,3,10,22-24,35-38	
21	8702171	TRANSMISSION CASE PLUG	1
22	8702172	SUCTION TUBE CLIP WASHER	1
23	8702173	SUCTION TUBE CLIP	1
24	8702174	SUCTION TUBE ASSEMBLY	1
25 THRU 34		NOT USED ON THIS MODEL	

CLARK

CLARK



CONVERTER HOUSING TO TRANSMISSION
CASE SPACER USED ONLY WITH 12
PLATE CLUTCH PACK ASSEMBLY.



SPECIAL SUMP

MACHINE	SECTION	2
-----	-----	-----
SWINGLOADER	DRIVE SYSTEM	
-----	-----	-----

ASSEMBLY
NUMBER

DESCRIPTION


1802018

TRANSMISSION ASSEMBLY
- TRANSMISSION CASE & REAR GROUP

ITEM NO.	PART NUMBER	DESCRIPTION	QTY. USED
35	8702175	RETAINING WASHER SCREW	2
36	8702176	RETAINING WASHER	1
37	8702177	SUCTION TUBE O-RING	1
38	8702178	SUCTION TUBE CLIP RIVET	1
39	8702179	OIL BAFFLE	1
40 THRU 43		NOT USED ON THIS MODEL	
-----	-----	-----	-----

CLARK

CLARK



MACHINE

SECTION

2

SWINGLOADER

DRIVE SYSTEM

ASSEMBLY
NUMBER

DESCRIPTION


1802018

TRANSMISSION ASSEMBLY
- REVERSE & HIGH SHAFT GROUP

ITEM NO.	PART NUMBER	DESCRIPTION	QTY. USED
1	8700217	REV. & 3RD CLUTCH SHAFT PISTON RING	3
2	8700218	FRONT BEARING RETAINER RING	1
3	8702144	REVERSE & 3RD SHAFT FRONT BEARING	1
4	8700218	FRONT BEARING RETAINER RING	4
5	8700221	CLTCH DRIVEN GEAR BRG-SHIELD MUST FACE OUT	1
6	8702181	CLUTCH DRIVEN GEAR BEARING SNAP RING	1
7	8702182	CLUTCH HUB OIL BAFFLE RING	1
8	8702183	END PLATE RETAINER RING	1
9	8702184	END PLATE	1
10	8702185	CLUTCH OUTER DISC	6
11	8702186	CLUTCH INNER DISC	6
12	8702187	CLUTCH PISTON	1
13	8702188	CLUTCH PISTON OUTER SEAL	1
14	8702189	CLUTCH PISTON INNER SEAL	1
15	8702190	REVERSE & 3RD CLUTCH DRUM & PLUG ASSEMBLY	1
16	8702189	CLUTCH PISTON INNER SEAL	1
17	8702188	CLUTCH PISTON OUTER SEAL	1
18	8702187	CLUTCH PISTON ASSEMBLY	1
19	8702186	CLUTCH INNER DISC	6
20	8702185	CLUTCH OUTER DISC	6
21	8702184	END PLATE	1
22	8702183	END PLATE RETAINER	1
23	8702191	SPRING RETAINER	1
24	8702192	PISTON RETURN SPRING	1
25	8702193	SPRING RETAINER	1
26	8702194	SPRING RETAINER SNAP RING RETAINER	1

CLARK

CLARK



MACHINE

SECTION

2

SWINGLOADER

DRIVE SYSTEM

ASSEMBLY
NUMBER

DESCRIPTION

1802018


TRANSMISSION ASSEMBLY
- REVERSE & HIGH SHAFT GROUP

ITEM NO.	PART NUMBER	DESCRIPTION	QTY. USED
27	8700239	SPRING RETAINER SNAP RING	1
28	8700224	CLUTCH DRIVEN GEAR BEARING	1
29	8702181	CLUTCH DRIVEN GEAR BEARING SNAP RING	1
30		NOT USED ON THIS MODEL	
31	8702191	SPRING RETAINER	1
32	8702192	PISTON RETURN SPRING	1
33	8702193	SPRING RETAINER	1
34	8702194	SPRING RETAINER SNAP RING RETAINER	1
35	8700239	SPRING RETAINER SNAP RING	1
36	8702196	3RD GEAR BEARING	1
37	8702197	3RD GEAR BEARING SNAP RING	1
38	8702182	CLUTCH HUB OIL BAFFLE RING	1
39	8702198	3RD GEAR BEARING SPACER	1
40	8702197	3RD GEAR BEARING SNAP RING	1
41	8702199	3RD GEAR BEARING - SHIELD MUST FACE OUT	1
42	8702200	REVERSE & 3RD SHAFT REAR BEARING	1
43	8702201	GEAR RETAINING RING	1
44	8702202	LOW CLUTCH DRIVE GEAR - 26 TEETH	1
45	8702203	3RD GEAR - 60 TEETH	1
46	8702204	CLUTCH DRIVEN GEAR - 28 TEETH	1



CLARK

CLARK



MACHINE	SECTION	2
-----	-----	-----
SWINGLOADER	DRIVE SYSTEM	
-----	-----	-----

ASSEMBLY
NUMBER

DESCRIPTION


1802018

TRANSMISSION ASSEMBLY
- OUTPUT SHAFT GROUP

ITEM NO.	PART NUMBER	DESCRIPTION	QTY. USED
1	8702244	LOW RANGE GEAR - 50 TEETH	1
2	8702245	SHIFT HUB	1
3	8702246	SLEEVE	1
4	8702247	HIGH RANGE GEAR - 48 TEETH	1
5	8702248	INNER RACE	1
6	8702249	BEARING	1
7	8702249	BEARING	1
8	8702250	THRUST WASHER	1
9	8702251	REAR BEARING CONE	1
10	8702252	REAR BEARING CUP	1
11	8702253	O-RING	1
12	8702254	O-RING	1
13	8702255	OIL SEAL	1
14	8702256	SCREW	4
15	8700344	LOCK WASHER	4
16	8702248	INNER RACE	1
17	8702249	OUTPUT GEAR BEARING	1
18	8702249	OUTPUT GEAR BEARING	1
19	8702257	OUTPUT SHAFT & BUSHING ASSY - INCLUDES 20	1
20	8700352	OUTPUT SHAFT BUSHING	1
21	8702250	OUTPUT GEAR THRUST WASHER	1
22	8702258	FRONT BEARING CONE	1
23	8702259	FRONT BEARING CUP	1
24	8702260	O-RING	1
25	8702261	SHIM (0.004")	AR
25A	8702262	SHIM (0.007")	AR

CLARK

CLARK



MACHINE

SECTION

2

SWINGLOADER

DRIVE SYSTEM

ASSEMBLY
NUMBER

DESCRIPTION


1802018

TRANSMISSION ASSEMBLY
- OUTPUT SHAFT GROUP

ITEM NO.	PART NUMBER	DESCRIPTION	QTY. USED
25B	8702263	SHIM (0.010")	AR
25C	8702264	SHIM (0.020")	AR
26	8702265	SHIFT HUB	1
27	8700330	PLUG	1
28	8702266	DISCONNECT HOUSING	1
29	8700344	LOCK WASHER	4
30	8702267	CAP SCREW	4
31	8702268	RETAINER RING	1
32	8702119	BEARING	1
33	8702268	RETAINER RING	1
34	8702271	OIL SEAL	1
35	8702272	DISCONNECT SHAFT	1
36	8700368	OIL SEAL	1
37	8702273	SHIFT RAIL	1
38	8700340	DETENT SPRING	1
39	8700339	DETENT BALL	1
40	8702274	SHIFT FORK	1
41	8700336	LOCK SCREW	1
42	8702275	OUTPUT SHAFT REAR BEARING CAP	1

CLARK

CLARK



MACHINE

SECTION

2

SWINGLOADER

DRIVE SYSTEM

ASSEMBLY
NUMBER

DESCRIPTION

1802018


TRANSMISSION ASSEMBLY

- HIGH & LOW RANGE SHIFT CONTROL GROUP

ITEM NO.	PART NUMBER	DESCRIPTION	QTY. USED
1	8700067	O-RING	1
2	8700365	RANGE SHIFT RAIL SUPPORT	1
3		PART OF ITEM 4	
4	8702214	SCREW & LOCK WASHER	2
5	8702277	RANGE SHIFT RAIL	1
6	8700368	OIL SEAL	1
7	8700137	DETENT PLUG	1
8	8700339	DETENT BALL	1
9	8700340	DETENT SPRING	1
10	8700336	SHIFT FORK LOCK SCREW	1
11	8702278	HIGH & LOW RANGE SHIFT FORK	1

CLARK

CLARK



MACHINE	SECTION	2
-----	-----	-----
SWINGLOADER	DRIVE SYSTEM	
-----	-----	-----

ASSEMBLY
NUMBER

DESCRIPTION


1802018

TRANSMISSION ASSEMBLY
- SOLENOID CONTROL VALVE ASSEMBLY

ITEM NO.	PART NUMBER	DESCRIPTION	QTY. USED
1	8702279	HOUSING GASKET	1
2	8702280	FORWARD SPOOL	1
3	8702281	FORWARD & REVERSE SPOOL SPRING	1
4	8702282	RANGE SPOOL SPRING	1
5	8702283	RANGE SPOOL (W/NEUTRAL)	1
6	8702284	O-RING	6
7	8702285	VALVE SPOOL STOP PLUG - INCLUDES ITEM 6	6
8	8702286	LOW SPEED SPOOL	1
9	8702282	SPRING	1
10	8702287	CONTROL VALVE ASSEMBLY INCLUDES ITEMS 2-11,24-29	1
11	8700145	PIPE PLUG	1
12	8702288	HOUSING GASKET	1
13	8701927	SOLENOID (12 VOLT) INCLUDES ITEMS 33-39	5
14	8702284	O-RING	5
15	8702289	O-RING	5
16	8702290	O-RING	5
17	8702291	SOLENOID CONTROL HOUSING	1
18	8700060	LOCK WASHER	5
19	8702292	CAP SCREW	5
20	8700060	LOCK WASHER	4
21	8702293	CAP SCREW	4
22	8700061	CAP SCREW	4
23	8700060	LOCK WASHER	4
24	8702282	SPRING	1

CLARK

CLARK



MACHINE	SECTION	2
-----	-----	-----
SWINGLOADER	DRIVE SYSTEM	
-----	-----	-----

ASSEMBLY
NUMBER

DESCRIPTION

1802018


TRANSMISSION ASSEMBLY
- SOLENOID CONTROL VALVE ASSEMBLY

ITEM NO.	PART NUMBER	DESCRIPTION	QTY. USED
25	8702294	2ND SPEED SPOOL	1
26	8702280	REVERSE SPOOL	1
27	8702295	SPEED SELECTOR SPOOL	1
28 & 29		NOT USED ON THIS MODEL	
30	8702289	O-RING	1
31	8702284	O-RING	1
32	8702296	SOLENOID PLUG	1
33	8702297	STOP NUT	5
34	8702300	COIL COVER	5
35	8702299	WASHER	5
36	8702298	COIL	5
37	8702290	O-RING	5
38	8702302	WASHER	5
39	8703533	CARTRIDGE ASSEMBLY - INCLUDES ITEMS 14-16	5

1 2 3 4

5 6 7 8

5 6 7 8



MACHINE

SECTION

2

SWINGLOADER

DRIVE SYSTEM

ASSEMBLY
NUMBER

DESCRIPTION


1802018

TRANSMISSION ASSEMBLY
- DRIVE FLANGE

ITEM NO.	PART NUMBER	DESCRIPTION	QTY. USED
1	8700068	INPUT FLANGE	1
2	8700065	NUT	1
3	8700066	WASHER	1
4	8700067	O-RING	1
5	8702303	OUTPUT FLANGE	2
6	8702304	NUT	2
7	8702305	WASHER	2
8	8702306	O-RING	2

CLARK

CLARK



MACHINE

SECTION

2

SWINGLOADER

DRIVE SYSTEM

ASSEMBLY
NUMBER

DESCRIPTION


1802018

TRANSMISSION ASSEMBLY
- FORWARD & SECOND SHAFT GROUP

ITEM NO.	PART NUMBER	DESCRIPTION	QTY. USED
27	8702186	CLUTCH INNER DISC	6
28	8702187	CLUTCH PISTON ASSEMBLY	1
29	8702188	CLUTCH PISTON OUTER SEAL	1
30	8702189	CLUTCH PISTON INNER SEAL	1
31	8702205	FWD. & 2ND SHAFT, CLUTCH DRUM & PLUG ASSY	1
32	8702189	CLUTCH PISTON INNER SEAL	1
33	8702188	CLUTCH PISTON OUTER SEAL	1
34	8702187	CLUTCH PISTON ASSEMBLY	1
35	8702185	CLUTCH OUTER DISC	6
36	8702186	CLUTCH INNER DISC	6
37	8702184	END PLATE	1
38	8702183	RETAINER RING	1
39 & 40		NOT USED ON THIS MODEL	
41	8702204	FORWARD CLUTCH DRIVEN GEAR - 28 TEETH	1
42	8702206	2ND GEAR - 22 TEETH	1

CLARK

CLARK



MACHINE

SECTION

2

SWINGLOADER

DRIVE SYSTEM

ASSEMBLY
NUMBER

DESCRIPTION


1802018

TRANSMISSION ASSEMBLY
- LOW SPEED SHAFT GROUP

ITEM NO.	PART NUMBER	DESCRIPTION	QTY. USED
1	8702183	RETAINER RING	1
2	8702184	END PLATE	1
3	8702185	CLUTCH OUTER DISC	9
4	8702207	CLUTCH INNER DISC	9
5	8702187	CLUTCH PISTON ASSEMBLY	1
6	8702208	CLUTCH OUTER SEAL	1
7	8702189	CLUTCH INNER SEAL	1
8	8702209	LOW SPEED CLUTCH SHAFT, DRUM & PLUG ASSY.	1
9	8702210	REAR BEARING	1
10	8700170	RETAINER RING	1
11	8702211	CLUTCH SHAFT PISTON RING	1
12	8702211	CLUTCH SHAFT PISTON RING	1
13	8702212	GASKET	1
14	8702212	REAR BEARING CAP	1
15-16	8702214	CAP SCREW & LOCK WASHER	5
17	8700145	PLUG	1
18	8702216	O-RING	1
19	8702217	SPRING RETAINER	1
20	8702192	PISTON RETURN SPRING	1
21	8702219	SPRING & SNAP RING RETAINER	1
22	8700239	SPRING RETAINER SNAP RING	1
23	8702220	BEARING RETAINER RING	1
24	8702182	CLUTCH HUB OIL BAFFLE RING	1
25	8702221	LOW SPEED GEAR BEARING ASSEMBLY	1
26	8702222	RING KIT	1
27	8700094	2ND GEAR BEARING	1
28		NOT USED ON THIS MODEL	
29	8702224	LOW SPEED CLUTCH SHAFT PILOT BEARING	1
30	8702225	LOW SPEED GEAR	1

CLARK

CLARK



MACHINE	SECTION	2
-----	-----	-----
SWINGLOADER	DRIVE SYSTEM	
-----	-----	-----

ASSEMBLY
NUMBER

DESCRIPTION

1802018

TRANSMISSION ASSEMBLY
- FORWARD & SECOND SHAFT GROUP

ITEM NO.	PART NUMBER	DESCRIPTION	QTY. USED
1	8700217	FORWARD & 2ND SHAFT PISTON RING	3
2	8700218	FRONT BEARING RETAINER RING	1
3	8700220	FORWARD & 2ND SHAFT FRONT BEARING	1
4	8700219	FRONT BEARING LOCATING RING	1
5	8700218	FRONT BEARING RETAINER RING	1
6	8700221	CLUTCH DRIVEN GEAR BEARING-SHIELD OUT	1
7	8702181	SNAP RING	1
8	8702182	CLUTCH HUB OIL BAFFLE RING	1
9	8702181	SNAP RING	1
10	8700224	CLUTCH DRIVEN GEAR BEARING	1
11	8700239	SNAP RING	1
12		NOT USED ON THIS MODEL	
13	8702194	SNAP RING RETAINER	1
14	8702193	SPRING RETAINER	1
15	8702192	PISTON RETURN SPRING	1
16	8702191	SPRING RETAINER	1
17	8702182	CLUTCH HUB OIL BAFFLE RING	1
18	8700239	2ND GEAR RETAINER RING	1
19	8700239	SNAP RING	1
20	8702194	SNAP RING RETAINER	1
21	8702193	SPRING RETAINER	1
22	8702192	PISTON RETURN SPRING	1
23	8702191	SPRING RETAINER	1
24	8702183	END PLATE RETAINER RING	1
25	8702184	END PLATE	1
26	8702185	CLUTCH OUTER DISC	6
-----	-----	-----	-----

SWINGMASTER CORPORATION

PARTS BOOK

MACHINE

SECTION

2

SWINGLOADER

DRIVE SYSTEM

ASSEMBLY
NUMBER

DESCRIPTION

1802018

TRANSMISSION ASSEMBLY
- IDLER SHAFT GROUP

ITEM NO.	PART NUMBER	DESCRIPTION	QTY. USED
1	8700218	RETAINING RING	1
2	8702227	FRONT BEARING	1
3	8702228	GEAR LOCATING RING	1
4	8702229	IDLER SHAFT	1
5	8702230	REAR BEARING LOCK BALL	1
6	8700344	LOCK WASHER	1
7	8700386	IDLER SHAFT BEARING CAP SCREW	3
8	8702233	IDLER SHAFT BEARING CAP SCREW	3
9	8700344	LOCK WASHER	1
10	8702234	IDLER SHAFT BEARING CAP	1
11	8702235	GASKET	1
12	8702236	NUT	1
13	8702237	LOCATING RING	1
14	8702238	REAR BEARING	1
15	8722239	IDLER SHAFT GEAR	1
16	8702240	SPACER	1
17	8702241	LOW RANGE GEAR	1
18	8702242	IDLE SHAFT REAR BEARING SPACER	1
19	8702243	SPEEDOMETER GEAR HOLE PLUG	1
20		NOT USED WITH THIS MODEL	1